



Start Table



Reach Table (adjustable height)



Steady Chair



Unity Stool



Share Bench



Share Bench with Back



Imagine Cube



Nature Table (adjustable height)



Imagine Stand



Imagine Play Kitchen

DIMENSIONS

	LENGTHS	DEPTH	HEIGHT
Start Table	47"	47"	13"
Small Reach Table (adjustable)	48"	48"	13-18"
Medium Reach Table (adjustable)	48"	48"	17"-24"
Steady Chair - 06"	12.5"	12"	06"
Steady Chair - 08"	12.5"	12"	08"
Unity Stool - 10"	11.5"	11.5"	10"
Unity Stool - 12"	11.5"	11.5"	12"
Share Bench - 08"	44"	12"	8"
Share Bench - 10"	44"	12"	10"
Share Bench - 12"	44"	12"	12"
Share Bench with Back - 06"	44"	12"	6"
Share Bench with Back - 08"	44"	44"	8"
Imagine Cube	32.5"	31"	30"
Small Nature Table (adjustable)	31"	23"	13-18"
Medium Nature Table (adjustable)	31"	23"	17"-24"
Imagine Stand	30"	31"	50"
Imagine Play Kitchen	30"	15"	4.25"



Straight Evergreen Shelf
24" Double



Curved Evergreen Shelf
24" Curved



Straight Evergreen Shelf
24" Single



Straight Evergreen Shelf
32" Double



Curved Evergreen Shelf
32" Curved



Evergreen Arch

DIMENSIONS

	LENGTHS	DEPTH	HEIGHT
24" Straight Evergreen Shelf - Double	48"	15"	24"
24" Curved Evergreen Shelf	32"	15"	24"
24" Straight Evergreen Shelf - Single	32"	15"	24"
32" Straight Evergreen Shelf - Double	48"	15"	32"
32" Curved Evergreen Shelf	32"	15"	32"
Evergreen Arch	24"	4"	44"